PART NAME	PART NUMBER
A. Barrel – Bolt Housing Assembly	
Barrel	001
Bolt Housing	002
Barrel Set Screw	2
Bolt Housing Front Retainer Screw	5
Bolt Housing / Grip Frame Rear Retainer Screw	003
Bolt Housing / Grip Frame Rear Retainer Screw Nut	004
Barrel – Air Receiver Band Front Sight	005
Front Sight Band Screw	006
B. Bolt Assembly	
Bolt Pellet Pusher	007
Bolt Pellet Pusher “O” Ring	13
Bolt Pellet Pusher Spring	008
C. Slide Assembly	
Slide with Rear Sight	009
Slide Cross Screw	010
Slide Lock	011
Slide Lock Spring	92019
Slide Lock Pivot Pin	012
D. Air Receiver Assembly	
Air Receiver	014
Charging Valve	015
Charging Valve Retainer Cap	18
Charging Valve “O” Ring	19
Inlet Valve Housing	20
Inlet Valve Seal “O” Ring	21
Inlet Valve Spring	22
Inlet Valve Retainer Pin	23
Charging Valve Filter Screen	24
Charging Valve CO_2 Cylinder Nozzle Locator	25
Charging Valve CO_2 Cylinder Nozzle Seat	26
Discharge Valve Seat	28
Discharge Valve Housing	016
Discharge Valve Stem	017
Discharge Valve Stem Washer	31
Discharge Valve Seal	32
Discharge Valve Spring	018
Discharge Valve “O” Ring	34
Air Chamber	019
Air Tube Passage	36
Air Tube Passage “O” Ring	37

Hammer	020
Hammer Cocking Stud	41
Hammer Spring	021
Hammer Spring Guide Stem	022
Hammer Spring Retainer	023

E. Grip Frame Assembly

Grip Frame	024
Grip Frame Retainer Screw	025
Grip Screw and Nut	026
Grip Panel (Left & Right)	027
Grip Pin	028
Safety Button	029
Safety Button Plunger	030
Safety Button Plunger Spring	92019
Sear	031
Sear Pivot Pin	90008
Sear Spring	032
Trigger	033
Trigger Pivot Pin	90008


ARMSCOR
A/P
25
24
19
23
18
005
015
21
20
22
2
5
012
009
013
010
011
92019
002
001
37
36
41
006
014
008
13
007
004
019
018
32
022
019
31
018
28
033
92019
031
020
021
023
034
032
030
026
027
028
90008
025
003
90008
028
029
024
026
027